

Acoustic Panel Installation Instructions

SUPPLIED HARDWARE:

Each panel comes with two 2" wide z-clips pre-installed on the back. You should also receive two additional z-clips along with four screws and four wall anchors to easily mount your panels on any flat wall surface.

TOOLS NEEDED: Tape Measure, Drill, Level, Pencil

STEP 1:

Before you begin, make sure that the z-clips you will install on the wall surface are positioned correctly so that they fit together with the clips on the back of the panel. Figure A shows a side view of the correct positioning.

STEP 2:

Install one of the z-clips using the included hardware, making sure that it is level. (We recommend drilling pilot holes and using the wall anchors, regardless of the type of wall surface.)

STEP 3:

Before installing the second z-clip, measure the distance between the inward sides of the two z-clips that are on the back of the panel. Measure the same distance from the inner side of the z-clip on the wall and mark it with a pencil. (See Figure B)

STEP 4:

Align the inward side of the second z-clip with the pencil mark on the wall. Use a level to make sure the top of the clip is straight across from the other one. Drill your pilot holes, and install the z-clip using the remaining wall anchors and screws.

STEP 5:

Mount the panel by gently sliding the z-clips on the back of the panel over the tops of both wall z-clips, and make sure the panel is secure on both sides.

